# **Electrical Engineering Preparation Summary**

### Your Name

### August 25, 2025

## **Contents**

1	Intr	oduction	2
2	Elec	etrical Machines	2
	2.1	Electromotive Force (EMF)	2
	2.2	Radial Speed	2
	2.3	Current Flow in the Circuit	3

#### 1 Introduction

This document provides a concise summary of key electrical engineering concepts focused on electrical machines, including electromotive force (EMF), radial speed, and current flow, to aid in preparation.

#### 2 Electrical Machines

#### 2.1 Electromotive Force (EMF)

**Electromotive Force (EMF)** is the voltage generated in a conductor moving through a magnetic field, such as in a generator or motor.

Formula: 
$$E = \frac{pN\Phi n}{a}$$

• Parameters:

- E: Induced EMF (V).

- p: Number of poles in the machine.

- N: Number of conductors.

-  $\Phi$ : Magnetic flux per pole (Wb).

- n: Rotational speed (rad s<sup>-1</sup>).

- a: Number of parallel paths in the winding.

• **Explanation**: The EMF is proportional to the number of poles, conductors, magnetic flux, and rotational speed, divided by the parallel paths. This is critical for understanding voltage generation in machines like generators.

• Example: A 4-pole generator with 100 conductors, a flux of 0.02 Wb, speed of 1200 rpm, and 2 parallel paths generates an EMF calculated by converting speed to radians per second (see below) and applying the formula.

#### 2.2 Radial Speed

**Radial Speed** (or angular speed,  $\omega$ ) represents how fast a rotor spins in a rotating machine, measured in rad s<sup>-1</sup>.

Formula: 
$$\omega = \frac{2\pi n}{60}$$

2

• Parameters:

-  $\omega$ : Angular speed (rad s<sup>-1</sup>).

- n: Rotational speed in revolutions per minute (RPM).

• Simple Explanation: This formula converts rotational speed from RPM to radians per second. One revolution equals  $2\pi$  radians, and dividing by 60 adjusts for seconds in a minute. For example, at 1200 RPM:

$$\omega = \frac{2\pi \cdot 1200}{60} = 40\pi \approx 125.66 \,\mathrm{rad}\,\mathrm{s}^{-1}.$$

• Why It Matters: Angular speed is used in EMF calculations to determine how fast the magnetic field changes, directly affecting voltage generation.

#### 2.3 Current Flow in the Circuit

**Current Flow** in a circuit (induit) of an electrical machine is determined by the difference between the EMF and the voltage across the circuit, accounting for the internal resistance.

Formula: 
$$I = \frac{E - V}{R}$$

• Parameters:

- *I*: Current flowing through the circuit (A).
- E: Electromotive force (EMF, V).
- V: Voltage across the circuit (V).
- R: Internal resistance of the circuit ( $\Omega$ ).
- Explanation: The current is driven by the difference between the generated EMF and the circuit's terminal voltage, divided by the internal resistance. The power consumed by the internal resistor is  $P = I^2 R$ , where I results from the voltage drop across the resistor, controlling current flow.
- Example: For an EMF of  $100 \, \text{V}$ , a circuit voltage of  $90 \, \text{V}$ , and an internal resistance of  $2 \, \Omega$ , the current is:

$$I = \frac{100 - 90}{2} = 5 \,\text{A}.$$

The power consumed by the internal resistor is  $P = 5^2 \cdot 2 = 50 \,\mathrm{W}$ .